







STEREO TUNER

FM 88 90 92 94 96 98 100 102 104 106 108 STEREO MHC
MW 540 600 700 800 1000 1200 1400 1600 K
LW 155 170 190 220 240 260 270 K

TIME SET HOUR MINUTE TIMER TIMER/SET MANUAL
AFC/BEAT ON OFF FM MW LW

BASS TREBLE BALANCE VOLUME
LOUDNESS FILTER HI MONO ON STEREO
POWER PHONES

AVASTAR STEREO AMPLIFIER

COUNTER RESET
METAL C/OZ NORMAL NOISE REDUCTION VU PHONO TAPE RADIO
TAPES SELECTOR POWER FUNCTION
LEFT RIGHT MIC
RECORD LEVEL

AVASTAR STEREO CASSETTE DECK





CAUTION
DISCONNECT THE MAINS PLUG FROM THE
WALLS WHEN SUPPLY SOCKET SWITCH IS ON.
HANDS SUPPLY 200V ~ 50Hz
INTERNAL BATTERY TYPE: NIMH 1.2V (41.5V (OFF))
MAIN UNIT 1.2V (41.5V (OFF))
CLOCK 1.5V (OFF)
EXTERNAL BATTERY TYPE: 
DISCONNECT FROM MAINS SUPPLY BEFORE REMOVING
BACK PANEL. Made in Japan

AMSTRAD

MODEL 8090

DISCONNECT THE MAINS PLUG FROM THE
SUPPLY SOCKET WHEN NOT IN USE.

MAINS SUPPLY: 240V ~ 50Hz

BATTERIES: MOBILE TAPE MODULE 6V --- 4x1.5V (HP7)

MAIN UNIT 12V --- 8x1.5V (HP11)

CLOCK 1x1.5V --- (HP7)

EXTERNAL BATTERY: 12V ---



DISCONNECT FROM MAINS SUPPLY BEFORE REMOVING
BACK PANEL.

Made in Japan

CLICK FUNCTION IS NOT
EXPLAINED IN INSTRUCTION BOOK.
BUT PLEASE NOTE THE CLOCK
CAN NOT BE USED TO SWITCH
ON RADIO. USE HOLD SWITCH
ON CASSETTE SECTION FOR
OTHER RECORDING.

10V DC
INPUT



R SPKRS L

675V (HP11)
SIZE (W×D×H)



AVX5050
MODEL B000
DISCONNECT THE MAINS PLUG FROM THE
SUPPLY SOCKET WHEN NOT IN USE.
MAINS SUPPLY: 240V ~ 50Hz
BATTERIES: MOBILE TAPE MODULE 6V --- 4x1.5V (HP7)
MAIN UNIT 12V --- 8x1.5V (HP11)
CLOCK 1x1.5V --- (HP7)
EXTERNAL BATTERY: 12V ---
DISCONNECT FROM MAINS SUPPLY BEFORE REMOVING
BACK PANEL.
Made in Japan

