



TASTEN-NUMMERN

66	64	65	57	56	49	48	41	40	33	32	25	24	16	79	10	11	3
68	67	59	58	50	51	43	42	35	34	27	26	17		18	20	12	4
70	69	60	61	53	52	44	45	37	36	29	28	19			13	14	5
SHIFT 21	71	63	62	55	54	46	38	39	31	30	22	SHIFT 21	15	↑0	.		
CTRL 23	COPY 9						47					ENTER 6	←8	↓2	→1		



▲ 72 ▼ 73 ◀ 74 ▶ 75 ⚡ 176 ⚡ 277

INKEY (Nummer) = AUS -1 SHIFT 32 CTRL 128 SHIFT-CTRL 160

FARBTABELLE

BASIC
HARDWARE

00 54h SCHWARZ	09 56h GRÜN	18 52h HELLGRÜN
01 44h BLAU	10 46h BLAUGRÜN	19 42h SEEGRÜN
02 55h HELLBLAU	11 57h HIMMELBLAU	20 53h HELLES BLAUGRÜN
03 5Ch ROT	12 5Eh GELB	21 5Ah LIMONENGRÜN
04 58h MAGENTA	13 40h GRAU	22 59h PASTELLGRÜN
05 5Fh HELLVIOLETT	14 5Fh PASTELLBLAU	23 5Bh PASTELLBLAUGRÜN
06 4Ch HELLROT	15 4Eh ORANGE	24 4Ah HELLGELB
07 45h PURPUR	16 47h ROSA	25 43h PASTELLGELB
08 4Dh HELLES MAGENTA	17 4Fh PASTELL MAGENTA	26 4Bh WEIß