

## Annexe 1

### Codes de contrôle et caractères ASCII

Décimal	Hexadécimal	Caractère ASCII
0	00	NUL (CTRL @)
1	01	SOH (CTRL A)
2	02	STX (CTRL B)
3	03	ETX (CTRL C)
4	04	EOT (CTRL D)
5	05	ENQ (CTRL E)
6	06	ACQ (CTRL F)
7	07	BEL (CTRL G)
8	08	BS (CTRL H)
9	09	HT (CTRL I)
10	0A	LF (CTRL J)
11	0B	VT (CTRL K)
12	0C	FF (CTRL L)
13	0D	CR (CTRL M)
14	0E	SO (CTRL N)
15	0F	SI (CTRL O)
16	10	DLE (CTRL P)
17	11	DC1 (CTRL Q)
18	12	DC2 (CTRL R)
19	13	DC3 (CTRL S)
20	14	DC4 (CTRL T)
21	15	NAK (CTRL U)
22	16	SYN (CTRL V)
23	17	ETB (CTRL W)
24	18	CAN (CTRL X)
25	19	EM (CTRL Y)
26	1A	SUB (CTRL Z)
27	1B	ESC
28	1C	FS
29	1D	GS
30	1E	RS
31	1F	US
32	20	SP
33	21	!
34	22	"
35	23	#
36	24	\$
37	25	%
38	26	&
39	27	'
40	28	(
41	29	)
42	2A	*
43	2B	+
44	2C	,
45	2D	-
46	2E	.
47	2F	/
48	30	0
49	31	1
50	32	2
51	33	3
52	34	4

Décimal	Hexadécimal	Caractère ASCII
53	35	5
54	36	6
55	37	7
56	38	8
57	39	9
58	3A	:
59	3B	;
60	3C	<
61	3D	=
62	3E	>
63	3F	?
64	40	@
65	41	A
66	42	B
67	43	C
68	44	D
69	45	E
70	46	F
71	47	G
72	48	H
73	49	I
74	4A	J
75	4B	K
76	4C	L
77	4D	M
78	4E	N
79	4F	O
80	50	P
81	51	Q
82	52	R
83	53	S
84	54	T
85	55	U
86	56	V
87	57	W
88	58	X
89	59	Y
90	5A	Z
91	5B	[
92	5C	\
93	5D	]
94	5E	^
95	5F	_
96	60	`
97	61	a
98	62	b
99	63	c
100	64	d
101	65	e
102	66	f
103	67	g
104	68	h
105	69	i
106	6A	j

Décimal	Hexadécimal	Caractère ASCII
107	6B	k
108	6C	l
109	6D	m
110	6E	n
111	6F	o
112	70	p
113	71	q
114	72	r
115	73	s
116	74	t
117	75	u
118	76	v
119	77	w
120	78	x
121	79	y
122	7A	z
123	7B	(
124	7C	)
125	7D	)
126	7E	-

