





DISC DRIVE

KEY NUMBERS

66	64	65	67	66	49	48	41	40	33	32	25	24	16	79	10	11	3
68	67	59	68	50	51	43	42	35	34	27	26	17	18		20	12	4
70	69	60	61	53	52	44	45	37	36	29	28	19			13	14	5
21	71	63	62	55	54	46	38	39	31	30	22	21			15	0	7
23	9						47						6		8	2	1

MASTER COLOUR CHART

BLACK	9 GREEN	18 BRIGHT GREEN
	10 CYAN	19 SEA GREEN
BLUE	11 SKYBLUE	20 BRIGHT CYAN
	12 YELLOW	21 LIME GREEN
	13 WHITE	22 PASTEL GREEN
	14 PASTEL BLUE	23 PASTEL CYAN
	ORANGE	24 BRIGHT YELLOW
	PINK	25 PASTEL YELLOW
	PASTEL MAGENTA	26 BRIGHT WHITE

CPC6128