


SONY[®]

C-1K

Cleaning Cassette / Cassette de Nettoyage



To clean the heads : Run both sides of this cassette through the recorder in the playback mode (Total time : about 1 minute).

Notes

- Dirty cleaning tape will not clean well. Use clean part.
- Use Sony Cleaning Kit to clean extremely dirty heads, pinch roller and capstan.

1.5m

Sony Corporation Tokyo Japan S.M.P.
Made in Japan/Fabriqué au Japon