

DISK DRIVE HEAD CLEANER FOR 3" DRIVES

Cleaning Activity Record Instructions:
Apply 5 drops of liquid to the cut out on the underside of
diskette. Insert diskette into drive according to directional
arrow. Operate drive 10-15 seconds. Remove diskette. Record
usage on label. Do not use diskette more than 15 times.


694 39.00



