



838 77.00

**MAGNETIC  
TECHNOLOGY  
MEDIA**



**WITH SOLVENT  
AVEC DISSOLVANT  
MIT LÖSUNG  
CON SOLVENTE**

**CLEAN LINE  
3" DISKETTE**

## CLEAN LINE 3" DISKETTE

### OPERATING INSTRUCTIONS

Wet the disc with 6-8 drops of the enclosed liquid, insert the cleaning disc in the "Drive". - Engage head (s) for about 60 seconds, then remove the diskette from the "Drive". - Do this operation twice a week. - Deplace the cleaning disc as soon as debris or impurities appear.

### MODE D'EMPLOI

Humidifier le disque avec 6-8 gouttes de liquide détergent, enfler un disque humidifié dans le "Drive". - Faire tourner le "Drive" pendant 60 seconds environ. - Enlever le disquette du "Drive". - Utiliser le disque de nettoyage au moins deux fois par semaine. - Remplacer le disque quand il parait malpropre.

### GEBRAUCHSANWEISUNG

6-8 Tropfen Reinigungsflüssigkeit auf das freie Diskettensegment sprühen und Diskette sofort ins "Drive" einschieben. - Drivekopf ca. 60 sek. lang reinigen. - Diskette aus der Maschine nehmen. - Vollziehen Sie Handlung zumindest zweimal pro woche. - Immer frische Reinigungsdisketten benutzen: ersetzen wenn Schmutzig.

### ISTRUZIONI PER L'USO

Umidificare con 6-8 gocce del liquido accluso la parte esposta del dischetto, introdurre il dischetto nel "Drive" e far girare il "Drive" a testine inserite per circa un minuto. - Togliere il dischetto dal "Drive". - Eseguire questa operazione ogni 10 ore di funzionamento. - Sostituire il dischetto non appena appaiono sullo stesso tracce di detriti o impurità.

Made in Italy

